

## **Time and Date Setting on AGFEO PBX Systems**

AGFEO systems lose their date and time when AC power is lost. This can have an effect on systems that use Day/Night Service.

You can reset the Date and Time with the following procedure:

Start Programming by lifting handset and dialling \*705 display should read "executed" or "completed"

Replace the handset

lift handset and change time by entering \*7381 and enter the time in this format **HHMM** display should read "executed" or "completed"

Replace the handset

Lift handset and change time by entering \*7382 and enter the date in this format **DDMMYY** display should read "executed" or "completed"

Replace the handset

The date and time will take a few seconds to update.

Exit programming mode by lifting the handset and dialling \*700 and the display should read "executed" or "completed"

**This procedure can be carried out from non-system phones correct steps are indicated by a confirmation tone.**